



SV150

Skyvent

Installation Instructions

SKYVENT 150

Step 1.

Fit roof flashing as per separate instructions.

Step 2.

Fit the rubber seal to top of flashing.

Step 3.

Attach one end of duct to the flange on the fan with cable tie provided.

Step 4.

Pass duct through the roof flashing and lower the adaptor with fan attached on to the roof flashing and fix with screws provided.

Step 5.

Using the spaces and screws provided fix the dome to the flashing. There will be a gap of about 30mm all round.

Step 6.

Using the template provided in the ceiling vent box, cut a hole in the ceiling to accommodate the ceiling vent.

Step 7.

Pass the duct through the hole, pull it fairly tight and cut it off about 100mm below the ceiling.

Step 8.

Attach the duct to the ceiling vent with the cable tie provided and fix the vent into the ceiling.

Step 9.

Have a registered electrician connect the power and switches.

